

APPENDIX A: EDGE CODE CHART

These charts reproduce the date edge codes from Kodak and Dupont motion picture film. To date your film, find the film's edge code and select the matching code on the chart. Kodak repeated symbols every 20 years, so you will need additional data to pinpoint the date. For 8mm edge codes used after 1965, see the Web site www.filmforever.org. Fuji film uses a four-digit code; the first two numbers represent the year of manufacture. For more on using edge codes for dating, see 3.3.

EASTMAN KODAK DATE CODE CHART			DUPONT DATE CODE CHART	
1922	1942	1962	● ■	1982 ● ■ X
1923	1943	1963	● ▲	1983 X ▲ X
1924	1944	1964	▲ ■	1984 ▲ ■ ▲
1925	1945	1965	■ ●	1985 ■ ● ▲
1926	1946	1966	▲ ●	1986 ▲ ● ▲
1927	1947	1967	■ ▲	1987 ■ ▲ ▲
1928	1948	1968*	● ● ●	1988 + + ▲
1929	1949	1969	+	1989 X + ▲
1930	1950	1970	▲ +	1990 ▲ + ▲
1931	1951	1971	● +	1991 X + X
1932	1952	1972	■ +	1992 ■ + ▲
1933	1953	1973	+ ▲	1993 + ▲ ▲
1934	1954	1974	+ ●	1994 + ● ▲
1935	1955	1975	+ ■	1995 + ■ ▲
1936	1956	1976	●	1996 X ● ▲
1937	1957	1977	■	1997 X ■ ▲
1938	1958	1978	▲	1998 X ▲ ▲
1939	1959	1979	● ●	1999 ● X ▲
1940	1960	1980	■ ■	2000 ■ ■ ▲
1941	1961	1981	▲ ▲	2001 ▲ ▲ ●
WHERE EASTMAN KODAK STOCK WAS MANUFACTURED				
SAFETY - ROCHESTER		SAFETY - CANADA		
SAFETY - ENGLAND		SAFETY - FRANCE		
SAFETY - AUSTRALIA				

Source: Adapted from a design by Lauren Jones-Joseph, Sabucat Productions.

*The code for 1968 is **++**.